




OPERATOR'S MANUAL

Model SPY50L-2S Push Spreader



Spyker Spreaders

Contact us at 800.972.6130
www.spyker.com

⚠ IMPORTANT

**This manual contains information for the safety of persons and property.
Read it carefully before assembly and operation of the equipment!**

TABLE OF CONTENTS

Safety 2

Part List 3

Hardware Identifier 4

Part Explosions 5-8

Assembly 9-15

Operation Instructions 16-17

Troubleshooting 17

Dial Settings 18

Deflector Settings 19

Warranty 20

OPERATE SAFELY

Read Before Using:

- Keep bystanders away when you operate this machine.
- Use this machine for intended purpose only.
- Do not let children or an untrained person operate machine.
- Keep all parts in good condition and properly installed. Fix damaged parts immediately. Replace worn or broken parts.
- Do not modify the machine or safety devices. Unauthorized modifications to the machine may impair its function and safety, and void the warranty.
- Do not let anyone sit or ride on equipment during operation.
- Wear substantial footwear and long trousers. Do not operate the equipment when barefoot or wearing open sandals.
- Do not wear loose fitting clothing that can get caught in moving parts.
- Always wear eye protection when operating the equipment.
- Stay alert for holes in the terrain and other hidden hazards.
- Watch out for traffic when crossing or near roadways.
- Before you operate any feature of this machine, observe your surroundings and look for bystanders.
- Always wash hands after contact with fertilizers and pesticides.
- Keep all nuts, bolts and screws tight to be sure the equipment is in safe working condition.
- Always remove material from hopper before attaching spreader on a vehicle-mounted spreader caddy.

Part List

DO NOT RETURN PRODUCT IF YOU ARE MISSING PARTS. PLEASE CALL: 1 (800) 972-6130

No.	Part #	Qty	Description
-----	--------	-----	-------------


1	1006084	5	Bolt, HexHd 1/4 x 3/4 SS
3	1005198	6	Nut, NylonLock, SS: 1/4"-20
4	1017543	1	Plate, Linkage
5	1017501	1	Bracket, Linkage
7	1017340	1	Control Linkage Assembly
8	1001255	3	Bolt, 1/4-20 x 1" HexHd,SS
9	1017551	1	Bolt, HexHd 1/4-20 x 1.50
10	1017503	1	Spring, Gate
11	1008431	1	Rate Gate Link, Formed
12	1017580	1	Plate, Hopper Bottom
13	1000203	1	Hopper Bottom Bearing
14	1004880	4	Bolt, HexHd 1/4 x 1/2 SS
15	1001521	2	Guide, Rate Gate/Accuway
16	1000210	1	Rate Gate
20	1000215	1	Pine Tree Clip
21	1000211	1	Dial Mount
22	1000213	1	Dial, Plastic
23	1000198	2	Felt Washer
24	1000051	1	Spreading Spinner
25	1000844	1	Agitator Blade
26	1017420	1	Spinner Shaft, 50 Lb
27	1000054	1	Roll Pin 1/8 x 7/8
28	1001301	2	3/8 Spinner Shaft Bushing
29	1001518	1	Pinion Gear - Metal
30	1001299	2	Gearbox Bushing 5/8"
31	1018126	1	Axle, Wheel SS
32	1001304	1	Dowel Pin, 3/16 x 1, SS
33	1001516	1	Bevel Gear-metal
34	1005389	1	Nylon Spacer, Pin Retain
35	1005336	1	Gear Box Cover Front
36	1005368	1	Grease Zerk 1/4 Drive IN
37	1017710	8	Bolt, PhlpHd 10-24 x 5/8" SS
38	1005337	1	Gear Box Cover Rear
39	1001308	8	Nut, NylonLock, #10-24 SS
40	1000225	2	Handle Grip
41	1019217	1	Weldment, Handle, SS
42	1000000	1	On-off Decal
51	1017502	1	Linkage
52	1019222	1	Handle, Lower, SS
57	1017504	2	Cap, Plastic
58	L-1744-6	1	Label, Serial#, Spyker
59	1019219	1	Medium Frame Weldment, SS
60	1019223	1	Stand, Med Frame, SS
63	1001607	2	Wheel, 13"
64	F-283	2	Bearing, Axle
67	1019225	1	Manual

No.	Part #	Qty	Description
-----	--------	-----	-------------


68	1017577	1	Cover, Hopper 50#
69	1017545	1	Screen, 50#
70	1019224	1	Hopper, 50# Blue
72	1017709	1	Decal Spyker Ice
74	1000053	1	Roll Pin, 1/8 x 3/4
75	1017730	1	Spacer, Plastic
77	1017776	1	Support Bracket
78	1001273	1	Hairpin (299 Agitator), SS
79	1017626	3	Label, Reflective
80	1019349	1	Deflector
81	1018993	4	Spacer, Plastic
82	1019231-LH	1	Mounting Bracket, LH
83	1019231-RH	1	Mounting Bracket, RH
84	1018708	4	Stiffener Plate
86	1018738	2	Spring
87	1018740	2	External Tooth Lockwasher
88	1004975	2	Nut, 1/4-20 Hex Flange
89	1007386	2	Bolt, Carriage, SS: 1/4"-20 x 3/4"
90	1019001	2	Bolt, HexHd: 1/4"-20 x 1-3/4"

92	1018577	1	Parts Bag
2	1001554	9	Washer, Nylon
3	1005198	23	Nut, NylonLock 1/4-20, SS
6	1001533	2	Nylon Flange Bushing
43	1001351	7	Washer, 1/4" SS
44	1007888	4	Bolt, HexHd, 1/4 x 2-1/4 SS
45	1017371	1	Bolt, HexHd, 1/4 x 3-1/4 SS
46	1001262	10	Bolt, HexHd, 1/4 x 1-1/2 SS
47	1017617	1	Plate, Guide
48	1007828	2	Knob, Handle
49	1017346	1	Spring, Control Lever
50	1017345	1	Lever, Control
53	1001315	4	Nut, NylonLock 5/16-18
54	45M1111SS	6	Washer, Flat, SS-5/16"
55	1008811	2	Bolt, Hex 5/16-18 x 1 SS316
56	1017374	2	Bolt, Carriage, 5/16 x 3/4
61	1005414	1	Rue Ring Locking Pin
62	1001350	5	Washer, Flat SS
65	1001274	1	Clevis Pin, 3/16 x 1-3/4
66	1019596	1	Cotter Ring
73	1017344	1	Control Lever Stop
76	1017725	2	Lock Washer Ext/Int Tooth 5/16

DO NOT RETURN PRODUCT IF YOU ARE MISSING PARTS. PLEASE CALL: 1 (800) 972-6130




Nut: Nylon Lock,
1/4" - 20 (x29)
1005198




Nut: Nylon Lock,
SS - #10-24 (x8)
1001308




Nut: Nylon Lock,
5/16" - 18 (x4)
1001315




Nut: Hex Flange
1/4" - 20 (x2)
1004975




Flange Bushing
Nylon (x2)
1001533




Washer,
Nylon (x10)
1001554




Washer,
Felt (x2)
1000198



Washer, SS
1/4" (x7)
1001351



Washer, Flat
SS, 5/16" (x6)
45M1111SS




Washer, Flat
SS (x5)
1001350



*Exterior circumference of washers can vary. These dimensions are a measurement of the internal diameter of the washer.


76

Washer, Lock; 5/16
External/Internal (x2)
1017225




87

Washer, Lock; SS, 1/4
(8-18) External Tooth (x2)
1018740




1

Bolt: Hex Head, SS
1/4 x 3/4" (x5)
1006084




8

Bolt: Hex Head, SS
1/4" - 20 x 1" (x3)
1001255




9

Bolt: Hex Head
1/4-20 x 1.50 (x1)
1017551



14

Bolt: Hex Head, SS
1/4 x 1/2" (x4)
1004880




44

Bolt: Hex Head, SS, 1/4 x 2-1/4" (x4)
1007888




45

Bolt: Hex Head, SS, 1/4 x 3-1/4" (x1)
1017371




46

Bolt: Hex Head, SS, 1/4 x 1-1/2" (x10)
1001262




55

Bolt: Hex Head, SS
5/16-18 x 1" (x2)
1008811




56

Bolt: Carriage
5/16 x 3/4" (x2)
1017374



90

Bolt: Carriage, SS
1/4" - 20 x 3/4" (x2)
1007386



91



Bolt: Hex Head, SS
1/4" - 20 x 1-3/4" (x2)
1019001



Part Explosions

DO NOT RETURN PRODUCT IF YOU ARE MISSING PARTS. PLEASE CALL: 1 (800) 972-6130


RATE GATE + AXLE / SPINNER



Part Explosions


DO NOT RETURN PRODUCT IF YOU ARE MISSING PARTS. PLEASE CALL: 1 (800) 972-6130

FRAME & HANDLE



DO NOT RETURN PRODUCT IF YOU ARE MISSING PARTS. PLEASE CALL: 1 (800) 972-6130


HOPPER



Part Explosions

DO NOT RETURN PRODUCT IF YOU ARE MISSING PARTS. PLEASE CALL: 1 (800) 972-6130

DEFLECTOR




No.	Part #	Qty	Description
3	1005198	6	Nut, NylonLock, SS: 1/4"-20
8	1001255	2	Bolt, HexHd, SS: 1/4"-20 x 1"
80	1019349	1	Deflector
81	1018993	4	Spacer, Plastic
82	1019231-LH	1	Mounting Bracket, LH
83	1019231-RH	1	Mounting Bracket, RH

No.	Part #	Qty	Description
84	1018708	4	Stiffener Plate
86	1018738	2	Spring
87	1018740	2	External Tooth Lockwasher
88	1004975	2	Nut, 1/4-20 Hex Flange
89	1007386	2	Bolt, Carriage, SS: 1/4"-20 x 3/4"
90	1019001	2	Bolt, HexHd: 1/4"-20 x 1-3/4"

ASSEMBLY

Remove the Part List (page 3) / Hardware Identifier (page 4)
and set aside for frequent reference during assembly.

For reassurance,
lay the nuts, bolts
and washers down
on page 4 to verify
you're using the
correct parts during
assembly.



Part List


No.	Part #	Qty	Description
1	1006084	5	Bolt, HexHd 1/4 x 3/4 SS
3	1005199	6	Nut, NylonLock, SS: 1/4"-20
4	1017543	1	Plate, Linkage
5	1017501	1	Bracket, Linkage
7	1017340	1	Control Linkage Assembly
8	1001255	3	Bolt, 1/4-20 x 1" HexHd SS
9	1017551	1	Spring, Gate
10	1017503	1	Rate Gate Link, Formed
11	1008431	1	Plate, Hopper Bottom
12	1017580	1	Hopper Bottom Bearing
13	1000203	1	Bolt, HexHd 1/4 x 1/2 SS
14	1004880	4	Guide, Rate Gate/Accessory
15	1001521	2	Rate Gate
16	1000210	1	Pine Tree Clip
20	1000215	1	Dial Mount
21	1000211	1	Dial, Plastic
22	1000213	1	Felt Washer
23	1000198	2	Spreading Spinner
24	1000051	1	Agitator Blade
25	1000844	1	Spinner Shaft, 50 Lb
26	1017420	1	Roll Pin 1/8 x 7/8
27	1000054	2	3/8 Spinner Shaft Bushing
28	1001301	1	Pinion Gear - Metal
29	1001518	1	Pinion Gear Bushing 5/8"
30	1001299	2	Gearbox Bushing SS
31	1018126	1	Axle, Wheel SS
32	1001304	1	Dowel Pin, 3/16 x 1, SS
33	1001516	1	Bevel Gear-metal
34	1005389	1	Nylon Spacer, Pin Retain
35	1005336	1	Gear Box Cover Front
36	1005368	1	Gear Zerk 1/4 Drive IN
37	1017710	8	Bolt, PhilHd 10-24 x 5/8" SS
38	1005337	1	Gear Box Cover Rear
39	1001308	8	Nut, NylonLock, #10-24 SS
40	1000225	2	Handle Grip
41	1019217	1	Weldment, Handle, SS
42	1019217	1	On-off Decal
43	1000000	1	Linkage
51	1017502	1	Handle, Lower, SS
52	1019222	2	Cap, Plastic
57	1017504	1	Label, Serial#, Spyker
58	L-1744-6	1	Medium Frame Weldment, SS
59	1019219	1	Stand, Med Frame, SS
60	1019223	2	Wheel, 13"
63	1001607	2	Bearing, Axle
64	F-283	2	Manual
67	1019225	1	Manual

©2021 Spyker Spreaders/A Brinly-Hardy Co.

Page 3

Hardware Identifier

ILLUSTRATIONS ON THIS PAGE ARE TO SCALE FOR FASTER IDENTIFICATION OF HARDWARE DURING ASSEMBLY.
DO NOT RETURN PRODUCT IF YOU ARE MISSING PARTS. PLEASE CALL: 1 (800) 972-6130



©2021 Spyker Spreaders/A Brinly-Hardy Co.


Page 4

1019225-D

Assembly

1. After removing all the parts from your box, place the pre-assembled hopper portion in your work area.


Start upside down and facing this direction:



2. Add 2 washers (62) to the wheel axle (31). Slide on the tire (63).

If last washer does not fit, remove tire & one of the interior washers.




Lock the wheel in place with the Clevis Pin (65) and Cotter Ring (66).



3. Add 1 washer (62) to the wheel axle (31), then slide on the tire (63) and an additional washer (62).


NOTE: If necessary, add the provided additional washer to reduce play in the axle.

Secure in place with the Rue Ring Locking Pin (61). (See figures 3b and 3c below).






4. Run two Hex Head bolts (44) through the frame (See Fig. 4 for alignment). Lower the tubing for the stand (59) on the bolts and secure in place with two Nylon Lock Nuts (3).

Tighten completely with a 7/16" socket & wrench.




Assembly

- 5a. The existing hardware (illustrated here) may need to be loosened for the next two steps.



- 5b. Remove hex head bolt (55), washers (54), & lock nut (53).

NOTE: Set aside, these will be reinstalled in step 6.





- 5c. Align the two holes of the Lower Handle (52) with the two holes of the outer, rear edges of the Frame (59). Place one of the Lock Washers with teeth (76) between the square hole of the Handle (52) and the curved slot on the Frame (59).

Starting from the inside of the Frame, run a Carriage Bolt (56) through the curved slot of the Frame (59). The Carriage Bolt will also pass through the square hole of the Lower Handle (52). *The end will be facing out.*

Loosely secure with a washer (54) and a Nylon Lock Nut (53). *Use a 1/2" Socket & Wrench.* Repeat on the other side.

! Do **NOT** tighten (yet).



6. Add one washer (54) to a hex head bolt (55). Starting from the outside edge, run the bolt through the circular holes of the Lower Handle (52), Frame (59) & Bracket (82 or 83), then **loosely** secure with another washer (54) & a Nylon Lock Nut (53).

Use a 1/2" Socket & Wrench.

Repeat on the other side.

! Do **NOT** tighten (yet).

7. Add the Handle Weldment (41) by lining it up on the Lower Handle tubing from step 6.

Secure the Handle in place by running four Hex Head Bolts (46) through the two handle ends from the outside. Tighten with four Nylon Lock Nuts (3) from the inside of the Lower handle (52).

Tighten with a 7/16" socket & wrench.





Fig. 7

Assembly

8. Determine the angle / height you will want your handle.

At the highest point, the handle will be 36" off the ground.




Tighten the hardware from steps 5 & 6 completely with a 1/2" socket & wrench.


9. Adding the Control Lever Stop.

Orientation is very important on this step.

- The Control Lever Stop (73) needs to be centered over the three holes on the right side of the handle. (Same side as the On/Off sticker).




- The lip of the the Control Lever Stop (73) needs to be **POINTED OUT & AWAY** from the handle tubing. (See Fig 9b).



- Leave the center hole open and run two hex head bolts (44) through the outer two holes of the Handle Weldment (41).

Bolts should also pass through the Control Lever Stop (73) & two 1/4" washers (43).



- Add two Nylon Lock Nuts (3) on the ends of the Bolt (44). Verify the Control Lever Stop (73) is centered (see Fig 9a) before tightening the Nuts (3) completely, securing everything in place.


10. Adding the linkage bar.

Orientation is very important on this step.

The Linkage (51) is a long, thin bar that connects the dial and the Control Lever.

Slide the Linkage (51) into the Linkage Assembly (7) from the side from left to right at a low angle, then lift it up toward the handle.

(See Fig. 10b)



Assembly

11. Adding the Linkage Guide Plate.

Orientation is very important on this step.

For this step, please follow the illustration notations below:




Fig. 11a Use the lower, circular hole of the Linkage Guide (47) and add it to the Linkage bar (51).




Fig. 11b Slightly lower linkage (51). Slide guide (47) down linkage & under the lower handle (52).





Fig. 11c Lift the linkage (51), aligning the top hole of the guide (47) with the hole of the lower handle (52).

12. Using Fig. 12 as a guide, insert a Hex Head Bolt (46) through the remaining hole at the top of the Lower Handle (52).

The bolt (46) should pass through the oval hole of the Linkage Guide (47) and a washer (43). Loosely secure in with a Nylon Lock Nut (3).

! Do **NOT** tighten (yet).



13. a) Adding the Control Lever

Start to slide a hex head bolt (45), through the remaining center hole on the handle.

End of the bolt comes out through the side of the handle with the On/Off sticker and the Control Lever Stop (73) that was added on Step 9.

Do **NOT** push the bolt 100% through (yet).

At a sideways angle, slide the bottom hole of the Control Lever onto the Linkage Bar (51).

See Fig. 13a

- b) Twist the Control Lever toward the hopper and then up, aligning the center hole of the Lever with the bolt (45) that was added in the last step.

Push the bolt (45) through the Control Lever.

See Fig. 13b

Fig. 13a




Fig. 13b

After adding the Control Lever to the Linkage Rod (51), rotate the lever forward into the ON position and push the bolt (45) through.





Fig. 13c



- c) Add the Nylon Flange Bushing (6) to the bolt (45). *Be sure to have the extended notch of the Flange facing the Lever.

Push the small extended notch of the Nylon Flange Bushing (6) into the center hole of the assembled Control Lever.

Add the Control Lever Spring (49) to the rest of the exposed bolt. **Loosely** keep parts in place with a Nylon Washer (2) & a Nylon Lock Nut (3).



Do **NOT** tighten (yet).

14. Checking the Rate Gate

Ensure the rate gate closes completely when the gate control lever is pulled back and locked into place.





Fig. 14

15. Rate Gate Adjustment

If the gate **IS** closed, skip to step 16.
If it is **NOT** closed, follow these steps:


- Ensure the hopper is empty.
- Turn the Spyker dial to #9. Remove the spring tension on the gate control lever by moving the lever to the Open position.



- Loosen the two bolts (44) that attach the Control Lever Stop (73).
- Slide the Control Lever Stop (73) forwards very slightly, then retighten bolts (44).


Assembly

- e) Move the gate control lever to CLOSED and re-evaluate the rate gate. If it is closed, then no further adjustment is necessary.
- f) If the rate gate is still open, then repeat steps 3-5 until the gate is closed.



16. Tighten the Bolts

The center bolt that runs through the Control Lever needs to be tightened enough to keep the Lever secure, but also be free enough to function.




Secure the Linkage Guide (47) in place by tightening* the bolt (46) that goes through the lower handle. (See step 12 on page 12 for clarification).

**Bolt can remain slightly loose, allowing Linkage Guide to move.*

18. Final Step

Place the Screen (69) down inside the hopper.

Attach the Hopper Cover (68) by hooking it around the rim of the Hopper.



Operation Instructions

WARNING: AVOID INJURY!

Chemicals can be dangerous. Avoid injury to operators or bystanders

ADDING MATERIAL TO THE HOPPER

- Make sure the rate gate is in the closed position.
- Read chemical container label for handling instructions. A Material Safety Data Sheet (MSDS) should be supplied by the chemical dealer and provides proper safety information.
- Wear proper clothing and safety equipment while handling or applying chemicals.
- Prohibit all smoking, drinking, and eating around chemicals.
- When spreading products containing herbicides, exercise extreme caution with respect to careless spreading and to wind-drift. Contact Of Some Products On Some Plants Can Be Fatal.
- Fill the spreader on a flat, level surface only. Fill on sidewalk, driveway, cardboard, etc. to avoid material loss.
- When filling hopper with material, always use screen to help break up clumps.

NOW YOU ARE READY TO SPREAD

- Keep spinner blade clean. Excess material build-up can cause an uneven spread pattern.
- Keep the spinner blade level when spreading.
- DO NOT overload. Maximum capacity of this model is 50 lbs.
- DO NOT use on windy days.
- Spread header strips at the ends of the area OPPOSITE of the direction of spreading. This will provide a “turn-around” area, an area to re-align the spreader for the return spread.
- TAKE A SIGHTING AT THE FAR END. Keep your eye on the sighting as you spread. You will not need to wonder where you are or where you have been. Continue until spreading is completed.

Tip: When not spreading (and if pushing the spreader some distance) tip the spreader so only the idle wheel is on the ground.

TIPS:

- Become familiar with the spreader before you put material in the hopper.
- Practice walking with the spreader, opening and closing the rate gate at the appropriate times.
- Travel at a constant speed and operate the spreader lever position. Remember: Open the rate gate after the spreader is in motion at operating speed (about 3 mph, or at a brisk walking pace).
- Close the rate gate while spreader is still at operational speed.
- The spread width ranges from 4 - 12 ft. wide depending on the density of the material and the operators walking speed.
- The spread thins or feathers at the outer edges, eliminating sharp, “Edge Of Spread” lines which cause stripes and streaks. Extra coverage can be given under trees and other heavy feeding areas without showing “Edge Of Spread” lines.

- Some products can be fatal to some plants
- Always remove material from hopper before attaching spreader on a vehicle-mounted spreader caddy.
- If a dial setting is not found, use the size and weight comparison table found in this manual. Determine a dial setting on the low side. If the setting proves to be too low, cover the area more than one time. A higher setting can be used when a proven dial setting is established.

NOTE: Published dial settings are approximate only. The operation of the spreader, the condition of the material (damp or dry or over-pulverized) and weather conditions, are all contributing factors. For these reasons, it is often a good idea to spread the area 2 times - or one-half rate - in cross directions (SEE INFORMATION ON ONE-HALF RATE DIAL SETTINGS ON PAGES 20-21). One-half rate dial settings are highly recommended under damp and humid conditions.

AFTER USE / CLEANING THE SPREADER:

CLEAN AND OIL SPREADER IMMEDIATELY AFTER EACH USE

METHOD #1	METHOD #2
Wipe spreader thoroughly with an oily cloth. Oil all bearings and bearing areas.	Wash, rinse, and dry the spreader. <i>Note: Drying takes time. Moisture trapped in bearing areas is slow to go.</i> Immediately after drying - oil all bearings and moving parts. Make certain all operations are thorough.

NOTE: Good "Dry Cleaning" (Method #1) is preferable to poor "Wet Cleaning" (Method #2).

- It is virtually impossible to have rust and corrosion on a clean, dry, oiled surface.
- Again - just before using - oil all bearings & moving parts.
- In storage, ideally the spreader should be hung by the handle. In any case, do not pile weight on the spreader, as excess weight over a period of time can distort the tires.


Oil Bearings and All Moving Parts

Make sure the spreader is running freely!

TROUBLESHOOTING / FREQUENTLY ASKED QUESTIONS

Problem	Diagnosis	Solution
Rate gate is binding and will not open/close properly.	Rate gate is jammed with debris.	Thoroughly wash out hopper and shut off plates with water. Ensure debris is not stuck between shut off plate and rate gate plate. - <i>Very slightly loosen bolt 1017551 (9) allowing linkage 1017340 (7) to float.</i> - <i>Very slightly loosen screw 1001255 (8) allowing linkage 1017340 (7) to float.</i> - <i>Slide bracket 1017776 (76) to the left or right.</i>
Lever control is slow to open or there is a grinding noise.	Lever Control (53) is rubbing against the Control Lever Stop (73).	Loosen spring (49) by loosening locknut (3). See fig 13C.
Lever control is making a grinding noise.	Linkage (51) is rubbing against the Guide Plate (47).	Loosen guide plate (47) and adjust up/down.

Dial Settings



NOTE: DIAL SETTINGS ARE APPROXIMATE ONLY!

The settings shown in the charts below are for reference only.

The RATE DIAL has 9 numbers with 10 stops between each number. This allows for accurate control of the spreading rate. The dial is set with only a turn, it will automatically lock into the set position. LINE UP THE DIAL NUMBER WITH THE DIAL INDICATOR.

WARNING: When spreading products containing herbicides, exercise extreme caution with respect to careless spreading and to wind-drift.


Use the rotary agitator only if needed. Free-flowing, lump-free materials will not require the agitator. The rotary agitator is easily installed or removed. Note the clockwise rotation and sweep. Place felt washer around spinner shaft before inserting agitator.

PRODUCT	PARTICLE SIZE	Lbs. per 1000 sq. ft.	DIAL SETTINGS Full Rate Once Over ↑↓	DIAL SETTINGS Half Rate Twice Over ↔↕↔
Fine Pellets		1	3.6	3.1
		2	4.0	3.5
		3	4.2	3.7
Mixed Fine Pellets		2	3.7	3.2
		4	4.7	4.1
		6	5.2	4.5
Small Pellets		2	3	2.2
		4	4.2	3.7
		6	4.5	4
Medium Nitrogen Pellets		1	3.5	3
		2	4.2	3.7
		3	4.7	4
Medium Pellets and Granuals		2	3.5	3
		4	4.2	3.8
		6	5.2	4.5
Large Heavy Pellets		2	3.8	3.3
		4	4.9	4.1
		6	5.9	4.9

RATE GATE DIAL SETTINGS	
LESCO SETTINGS	SPYKER SETTINGS
23	5.5
22	5.2
21	4.9
20	4.6
19	4.3
18	4.0
17	3.7
16	3.5
15	3.2
14	2.9
13	2.5
12	2.2
11	1.9
10	1.6
9	1.1


Deflector Settings

WIDENING THE SPREAD AREA




HIGHEST SETTING = 0% DEFLECTION

When the deflector is at the highest position, it enables a full spread pattern.




NARROWING THE SPREAD AREA




LOWEST SETTING = 100% DEFLECTION

When the deflector is at the lowest position, the spread width will be approximately 3 feet.



STRIPING ISSUES?


IF YOU FIND THAT THE MATERIAL IS STRIPING HEAVY ON THE LEFT SIDE OF THE SPREAD WHEN THE DEFLECTOR IS IN USE:
Reduce the gate opening until the distribution is uniform.



ADJUSTING THE DEFLECTOR

1. To move the deflector, stand in front of the spreader and plant your feet just before both wheels to prevent movement.
2. Grasp the deflector (as illustrated here) on both sides and pull toward yourself while raising or lowering to the desired setting.

NOTE:
Moving
the deflector
UP increases
the spread
width.





WARRANTY

1 YEAR LIMITED WARRANTY

This is warranted to the original purchaser only. Spyker will replace parts with defects in materials and workmanship, for a period of one year from the date of purchase.

For Spyker Spreaders—a Brinly-Hardy Company, products employing metal gear systems, pinion and bevel, these metal gears, only, not inclusive of any other parts or materials, are warranted for the life of the spreader, not to be used for replacement or repair past original purchase.

Spyker Spreaders will not be liable for any loss, damage or expense including, but not limited to, consequential or incidental damages, arising from the operation, condition or use of the item. The sole and exclusive remedy against Spyker Spreaders being the replacement of the defective parts. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

This express warranty, which is applicable only to the original purchase, is in lieu of and excludes all other warranties, whether expressed or implied by operation of law or otherwise, including any warranty of merchantability or fitness for particular purpose.

SPYKER SPREADERS

Jeffersonville, IN 47130 USA

Phone: 800.972.6130

www.spyker.com