

# Creedmoor Polecat Scope Head

(shown mounted on 3/4" stand with scope, adjustments applicable for all polecat heads)



**Step 1:** Make sure you have the parts shown here (stand not shown)



**Step 2:** This step will only be necessary if the stop collar is too tight to fit over the lower scope extension. If it is, remove the allen screw and spread the stop collar slightly by using a flat-head screwdriver. Once you have done this, position the collar on the stand at the approximate height needed for the prone position, or at least high enough to keep the scope from slamming into the ground should the head come loose.



**Step 3:** Slide the head onto the pole and attach the scope. (The included rubber o-ring goes between the had and the stop collar)



**Step 4:** The knurled knob on the end of the head is used to tighten the head to the stand. Prior to using the scope stand for the first time, it will be necessary to pre-tension the horizontal and vertical movements. While moving the scope slightly adjust the threaded stop collar on the end. Twist the collar clockwise to tighten, the opposite direction to loosen. Tighten the allen screw once desired tension is achieved.



**Step 5:** To adjust the horizontal pre-tension, follow the same procedure as outlined in step 4, but adjusting the collar directly above the scope.

You are now ready to begin using your scope stand. You may experience slight changes in the pre-tension after a short period. This pre-tension may be adjusted at any time.

Thank you for your purchase, and good shooting.

Dennis DeMille  
GM, Creedmoor Sports