ASSEMBLYINSTRUCTIONS

Quarter Round Étageres à Fleurs

All hardware comes pre-attached to the product, Remove it and re-attach it as needed during assembly

On a soft, level surface, unpack and identify the following component parts.

- Bottom Shelf (1)
- Middle Shelf (1)
- Top Shelf (1)
- Legs (3)
- 27 3/4" Vertical Supports (2)
- 12 3/4" Vertical Supports (6)
- 21 Bolts, 1 Allen key

Please read the instruction completely prior to assembly. The only tools required are the enclosed Allen key. (Do not use the to secure the bolts until assembly is complete; hand tighten until snug).

1. Attach the three legs to the bottom shelf as shown. Place the groove in the leg against the bottom shelf with the bent "foot" facing inward. Insert a bolt through the predrilled holes and fasten it using Allen key provided.

- 2. Attach the two 27 3/4" vertical supports to the bottom shelf. With the bent "foot" of each support facing inward, place the corner of the shelf into the groove in the supports. When the piece are allgned, insert a bolt through the predrilled holes and fasten using the Allen key.
- 3. Set the bottom shelf upright on to its legs. Connect three 12 3/4" vertical supports to the middle shelf. (Refer to the diagram). Place the corner of the middle shelf into the corresponding groove in the 12 3/4" supports and secure with two bolts. Anchor the 12 3/4" support to bottom shelf with tree bolts.
- 4. Attach three 12 3/4" supports to the top shelf Align the corners of top shelf with the groove in the 27 3/4" supports, secure with two bolts, and bolt the 12 3/4" supports onto the middle shelf.
- 5. Tighten each bolt with the Allen key.

