Page

- To Use This Chart: 1. Identify the metal category you will be measuring: pure silver, pure gold and silver alloys, or gold alloys-platinum-palladium.
 - 2. Select the column of your coin or bar thickness from the row of the metal you selected.
 - 3. Move down in the column until you are in the same row as the correct diameter/width of the item you are measuring.
 - 4. In the intersection of that row and column is(are) your best choice(s) for sensors to use.

note: There is a millimeter scale on the top of the Precious Metal Verifier that you can use to get the diameter/width and sample thickness if you don't already know what it is.

Metal Type	Thickness (mm)								
Pure Silver (.999&.9999)	0.4-0.8		0.8-1.0	1.0	0-3.3	3.3-4		1.0	4.0+
Pure Gold & Silver Alloys*	0.4-0.8		0.8-1.1	1.	1-3.3	3.3-4.5		1,5	4.5+
Gold Alloys*, Platinum & Palladium	1.0-1.7		1.7-2.4	2.4	4-6.5	6.5-7		7.0	7.0+
Diameter/Width (mm)									
30+	Large, C, N	Large	Main, C	Λ	/lain	Λ	1ain	Bullion, C, N	Bullion
30+ 24-30	Large, C, N Large, C, N			N Large		N Large		Bullion, C, N Bullion, C, N	Bullion Bullion, N
		Large		Large				Bullion, C, N	
24-30	Large, C, N	Large L	Main, C, N	Large La	Main, N		Main, N	Bullion, C, N e,N	Bullion, N

C - use calibration disk.

N - Can't make numismatic case (slab) measurements, but plastic bags/packaging are okay. note: A smaller sized sensor can always be used but is subject to greater surface variation effects, and will not penetrate as deeply in the sample.

^{*}Silver alloys include: 90%-coin silver, Morgan, Peace, and Trade dollars, sterling silver, Britannia silver, and 80% silver.

^{*} gold alloys include: 22K - Krugerrand, American Eagle gold, and 90% gold.

^{*} minimum thickness for rhodium and 98.6% gold is 1.6 times the minimum for pure silver.