

3807

Digital Kitchen Scale
Balance de Cuisine Numérique
Báscula Digital de Cocina

Thank you for purchasing a Taylor® digital kitchen scale. Your Taylor® scale is an example of superior design and craftsmanship. Please read this instruction manual carefully before use. Keep these instructions handy for future reference.

Battery Installation

1. Use 2 AAA batteries (included. Remove any plastic wrap from the batteries before proceeding). Always replace all batteries at the same time; do not combine old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (Ni-cad, Ni-mh, etc.) batteries. Do not dispose of batteries in fire, as batteries may explode or leak.
2. Remove the battery compartment cover on the bottom of the scale.
3. Place the batteries into the battery compartments according to the "+," and "-" polarity symbols in the battery compartment.
4. Replace the battery compartment cover.

NOTE: Please recycle or dispose of batteries per local regulations.

WARNING: Batteries may pose a choking hazard. As with all small items, do not let children handle batteries. If swallowed, seek medical attention immediately.

PRECAUTION: Do not dispose of batteries in fire. Batteries may explode or leak. Remove the batteries if the scale will not be used for a long period of time.

Low Battery

Your Taylor® scale is equipped with a low battery indicator. A low battery symbol will appear in the upper left corner of the LCD screen or readings will grow dim or become irregular if the batteries need replacement.

General Weighing Operation

1. Place the scale on a hard, level surface.
2. Press the "TARE/0" button to turn the scale on. The display will show "0.0000" and then zero when it is ready for use. If the display does not show zero, press the "TARE/0" button and wait a few seconds. The scale will reset (tare) to zero.
3. Your scale weighs in pounds/ounces (lb oz), grams (g) and kilograms (kg). Press the "UNIT" button to change the units of measurement.
4. Place the item to be weighed on the center of the platform. The weight will display. As you add weight, the weight displayed increases.
5. The scale will turn off automatically within 1 minute of non-use or if there is no change in weight. To turn the scale off manually, press and hold the "TARE/0" button until the scale turns off.

Tare Operation

You may wish to weigh ingredients in a bowl or other container (not included). In this case, you will need to tare, or offset, the weight of the bowl so that only the weight of the ingredients is displayed.

1. Choose a container that will safely balance on the platform without tipping or falling. Do not use a heavy container, as this might reduce the maximum capacity of the scale.
2. While the scale is off, place the empty container on the scale platform. Turn the scale on. The display will turn on and then show zero. The weight of the container has been zeroed out.
3. Add the ingredient to be weighed. The weight of the ingredient alone will display.
4. The weight of additional ingredients may be tared out as well. For example, if a recipe calls for ½ lb rice and ½ lb beans, place the rice into the bowl. Once the correct amount of rice is weighed, press "TARE/0" to reset the display to zero. Add the ½ lb of beans. Both ingredients have been accurately weighed in the same bowl.
5. When weights have been tared out, the display will show a negative number when the items are removed from the scale. To reset the scale back to zero for a new measurement, press "TARE/0" to reset the display to zero.

Precautions

1. Clean exposed parts with a soft, slightly damp cloth. To remove stains, use a mild soap. Never use detergents, excess water, treated cloths, harsh cleaning agents, or sprays. Avoid contact with acids, such as citrus juices. DO NOT immerse the electronic scale in water or wash in a dishwasher.
2. Do not tamper with the scale's internal components. Doing so will invalidate the warranty on this unit and may cause damage. The scale contains no user-serviceable parts.
3. Although your scale is designed to be maintenance-free, it contains sensitive electronic parts. Avoid rough treatment. Treat it with care to ensure the best performance.
4. This scale is intended for home/consumer use only. It is not intended for commercial or medical use.
5. This scale is designed to read weights up to 11 lb x 0.1 oz / 5000 g x 1 g / 5 kg x 0.001 kg. To prevent damage, do not place more than 11 lb / 5000 g / 5 kg on it.
6. Do not store scale where you store cleaning chemicals. The vapors from some household products may affect the electronic components of your scale. Do not store scale on its side.
7. This scale is an extremely sensitive weighing device. In order to prevent run down of the battery, do not store anything on the scale.
8. Do not dispose of batteries in fire. Batteries may explode or leak. Remove the batteries if the scale will not be used for a long period of time.
9. "UnSt" = Unstable Warning. Should "UnSt" appear on the display, this indicates the scale is unstable. Place the scale on a hard, level surface during use.
10. "EEEE" = Overload Warning. Should "EEEE" appear on the display during a weighing, this indicates that the maximum weighing capacity has been exceeded. Remove the weight immediately; otherwise, permanent damage could occur.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separating distance between the equipment and receiver.

In weight, to turn the scale off manually, press and hold the "TARE/O" button until the scale turns off.

Tare Operation

You may wish to weigh ingredients in a bowl or other container (not included). In this case, you will need to tare, or offset, the weight of the bowl so that only the weight of the ingredients is displayed.

1. Choose a container that will safely balance on the platform without tipping or falling. Do not use a heavy container, as this might reduce the maximum capacity of the scale.
2. While the scale is off, place the empty container on the scale platform. Turn the scale on. The display will turn on and then show zero. The weight of the container has been zeroed out.
3. Add the ingredient to be weighed. The weight of the ingredient alone will display.
4. The weight of additional ingredients may be tared out as well. For example, if a recipe calls for ½ lb rice and ½ lb beans, place the rice into the bowl. Once the correct amount of rice is weighed, press "TARE/O" to reset the display to zero. Add the ½ lb of beans. Both ingredients have been tared out; the display will show a negative number when the items are removed from the scale. To reset the scale back to zero for a new measurement, press "TARE/" to reset the display to zero.

Precautions

1. Clean exposed parts with a soft, slightly damp cloth. To remove stains, use a mild soap. Never use detergents, excess water, treated cloths, harsh cleaning agents, or sprays. Avoid contact with acids, such as citrus juices. DO NOT immerse the electronic scale in water or wash in a dishwasher.
 2. Do not tamper with the scale's internal components. Doing so will invalidate the warranty on this unit and may cause damage. The scale contains no user-serviceable parts.
 3. Although your scale is designed to be maintenance-free, it contains sensitive electronic parts. Avoid rough treatment. Treat it with care to ensure the best performance.
 4. This scale is intended for home/consumer use only. It is not intended for commercial or medical use.
 5. This scale is designed to read weights up to 11 lb x 0.1 oz / 5000 g x 1 g / 5 kg x 0.001 kg. To prevent damage, do not place more than 11 lb / 5000 g / 5 kg on it.
 6. Do not store scale where you store cleaning chemicals. The vapors from some household products may affect the electronic components of your scale. Do not store scale on its side.
 7. This scale is an extremely sensitive weighing device. In order to prevent run down of the battery, do not store anything on the scale.
 8. Do not dispose of batteries in fire. Batteries may explode or leak. Remove the batteries if the scale will not be used for a long period of time.
 9. "UnSt" = Unstable Warning. Should "UnSt" appear on the display, this indicates the scale is unstable. Place the scale on a hard, level surface during use.
 10. "EEEE = Overload Warning. Should "EEEE" appear on the display during a weighing, this indicates that the maximum weighing capacity has been exceeded. Remove the weight immediately; otherwise, permanent damage could occur.
- Caution:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- Note:** This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

One (1) Year Limited Warranty

Taylor® warrants this product to be free from defects in material or workmanship (excluding batteries) for one (1) year from the original purchaser from date of retail purchase. It does not cover damages or wear resulting from accident, misuse, abuse, commercial use, or unauthorized adjustment and/or repair. If service is required, do not return to retailer. Should this product require service (or replacement at our option), please pack the item carefully and return it prepaid, along with store receipt showing the date of purchase and a note explaining reason for return to:

Taylor Precision Products
2220 Estrada Del Sol, Suite A
Las Cruces, New Mexico 88001 USA
www.shopTaylorusa.com
Email: prodsupport@taylorusa.com

There are no expressed warranties except as listed above. This warranty gives you specific legal rights, and you may have other rights which vary from state to state. For additional product information, or warranty information outside the USA, please contact us through www.shopTaylorusa.com.

©2016 Taylor Precision Products and its affiliated companies. Taylor® is a registered trademark of Taylor Precision Products, and its affiliated companies. All rights reserved.

Made to our exact specifications in China.
Not legal for trade.