## **OPERATING INSTRUCTIONS**

## STEP 1

Place proper amount of chemical (powder or liquid) into jar to make desired number of gallons to be sprayed. Fill jar with proper amount of water for gallons to be sprayed and mix well (see mixture example).

### **MIXTURE EXAMPLE**

If chemical product calls for 1 tablespoon per gallon and you want 5 gallons of finished spray, place 5 tablespoons of product into jar and fill with water to the 5 gallon mark on side of jar.

#### **STEP 2**

Attach sprayer head to jar to prevent any spillage. Firmly thread hose-end connector to the end of garden hose. Turn water valve (counterclockwise) to **OFF** position. Turn on water faucet.

## IMPORTANT

Clean sprayer and jar after each use to prevent mixture and contamination between different chemicals. Rinse jar and refill with clean water, and spray for approximately 1 minute.

© 2015 Manufactured for H. D. Hudson Manufacturing Company, Lowell, MI 49331. Made in the USA. 871-045 Instruction

#### CONVERSION OF LIQUID MEASUREMENTS

 $1 \text{ tbsp} = 3 \text{ tsp} = \frac{1}{2} \text{ fl } \text{oz} = 15 \text{ ml} \bullet 2 \text{ tbsp} = 6 \text{ tsp} = 1 \text{ fl } \text{oz} = 30 \text{ ml} \bullet 16 \text{ tbsp} = 1 \text{ cup} = 8 \text{ fl } \text{oz} = 240 \text{ ml} \bullet 8 \text{ fl } \text{oz} = \frac{1}{2} \text{ pint} = 240 \text{ ml} 16 \text{ fl } \text{oz} = 1 \text{ pint} = 480 \text{ ml} \bullet 32 \text{ fl } \text{oz} = 1 \text{ quart} = 2 \text{ pints} = 960 \text{ ml} \bullet 128 \text{ fl } \text{oz} = 1 \text{ gallon} = 3.8 \text{ liters}$ 

# STEP 3

To spray your mixture turn the valve (clockwise) to the **ON** position. Valve must be fully open for best results. To water your plants turn back to the **WATER** position. To shut off water turn back to the **OFF** position.